

Mickey Mouse Express Ready-To-Play Set 7-11773

All aboard the Mickey Mouse Express! Help with Mickey's special delivery and join Mickey, Minnie, Donald Duck and Goofy to spread the Christmas spirit in this present filled Disney set! Bring a dose of holiday cheer under your tree this year with these iconic characters dressed in their Christmas best!

FEATURES:

- 37 Piece Set
 - 4 Train pieces Engine, Tender, Boxcar & Caboose
 - Engine Requires six C Cell Batteries (not included)
 - 24 curved & 8 straight plastic track pieces
 - RC Remote Control (requires three AAA batteries-not included)
- Authentic Train Sounds & Christmas Announcements!
- Engine has working headlight!

UPC Code: 023922010964 Individual Carton: (L)22.37" x (D)4.8" x (H)18" Master Carton: (L)22.88" x (D)5.3" x (H)19" Master Carton Weight: 11.24 lbs Packaging Language: English, French



